



L.P. GAS CYLINDER INSTALLATION INSTRUCTIONS

HOLDEN COMMODORE / STATESMAN VT, VX, VY, VZ MODELS (1997 – 2006)

This Automotive LP Gas cylinder must be installed in the vehicle in strict accordance with the latest requirements of AS/NZS1425. Any modifications to the cylinder will render the warranty null and void.

General Cylinder Specifications:

DIAMETER : 360mm	LENGTH : 1020mm
WATER CAPACITY: 95L	L.P GAS CAPACITY : 76L
VALVE ORIENTATION : 30 degrees	

Installation:



1. This cylinder is designed to be mounted in the luggage compartment, below the parcel shelf.



2. Remove the floor mat for the luggage compartment.



3. Remove the bottom section of the back seat by pulling the two release hooks on either side of the seat. Un-bolt and remove the top section of the back seat.



4. Un-bolt the ski hatch and place the cylinder into position ensuring the cylinder is not touching any part of the vehicle.



5. Using the bolt pack and brackets supplied fix the cylinder / ski hatch into position.



6. Mark the rear holes with a marker. Un-bolt and remove the cylinder. Drill where marked to suit M12 bolts.



6. Re-fit the cylinder and fix into position using the bolt pack and brackets / backing plates supplied with the cylinder. Cut the floor mat to accommodate.



7. Connect the cylinder as per AS1425.