

L.P. GAS CYLINDER INSTALLATION INSTRUCTIONS

HOLDEN COMMODORE / STATESMAN & TOYOTA LEXEN SEDANS (1988 – 1997)

Commodore Sedans - VN, VP, VR, VS Models.

Statesman Sedans - VQ, VR, VS Models.

Lexen Sedan - VN, VP, VR, T4, T5 Models.

This Automotive LP Gas cylinder must be installed in the vehicle in strict accordance with the latest requirements of AS/NZS1425. Any modifications to the cylinder will render the warranty null and void.

GENERAL CYLINDER SPECIFICATION:

DIAMETER : 360mm	LENGTH : 940mm
WATER CAPACITY: 85L	L.P GAS CAPACITY : 68L
VALVE ORIENTATION : 30 degrees	

Installation:

***Note: I.R.S kit required to fit cylinder if vehicle is fitted with Independent Rear Suspension.**



1. This cylinder is designed to be mounted in the luggage compartment, below the parcel shelf.



2. Lay down the ski hatch and remove the floor mat from the boot. Place the cylinder into position ensuring it does not touch any part of the vehicle.



3. Mark the mounting holes with a permanent marker and remove the cylinder. Drill the holes where marked using a 13mm dia drill bit.



5. Place the cylinder back into the vehicle and using the bolts and washers supplied. Bolt down the vertical brackets first via the boot followed by the horizontal brackets via the ski hatch. Cut and re-fit boot mat to suit.



6. Access to mounting points via the ski hatch.