



## L.P. GAS CYLINDER INSTALLATION INSTRUCTIONS

### FORD BA – BF FALCON / FAIRMONT / FAIRLANE SEDAN

This Automotive LP Gas cylinder must be installed in the vehicle in strict accordance with the latest requirements of AS/NZS1425. Any modifications to the cylinder will render the warranty null and void.

#### General Cylinder Specifications:

DIAMETER : 310mm	LENGTH : 960mm
WATER CAPACITY : 65L (Water)	L.P GAS CAPACITY : 52L
VALVE ORIENTATION : 30 degrees.	

#### Installation:



- 1). This cylinder is designed to be mounted in the vehicle luggage compartment, below the parcel shelf.



- 2). Lay the back seats down and remove the floor mat and side carpet mouldings.



- 3). Loosely fix the attachment brackets to the cylinder and position the cylinder into the boot of the vehicle.



- 4). Pack the cylinder at both ends to give an even 10mm clearance between the floor and cylinder. (This also allows for the thickness of the carpet).



- 5). Ensure there is adequate clearance all the way around the cylinder and mark the mounting hole centres with a visible marker.



- 6). Remove the cylinder and drill 3mm pilot holes where marked. Before proceeding, check if the 75 x 75mm backing plates will fit between the reinforcement ribs under the wheel arch in the location just drilled. Drill out the pilot holes using a 11mm drill bit to suit an M10 bolt.



- 7) Re-fit the side carpet mouldings and floor mat. Cut the 4 holes drilled into the wheel arch from the side carpet mouldings and re-position the cylinder and again check the clearance. Bolt the cylinder to the vehicle, connect and test in accordance with AS1425.